



D749MA – SAFETY CONTACTS


LED DL3 – “STOP” EMERGENCY BUTTON (wire terminals 5-6)



LED DL4 – INSIDE PHOTOCELLS (wire terminals 7-8)



LED DL5 – OUTSIDE PHOTOCELLS (wire terminals 7-9)



LED DL6 – SAFETY EDGE (wire terminals 7-10)

